

Index

A

- Activation
 - energy, 592
 - fatigue crack growth, 142, 145
 - thermal, 592
- Aging
 - fatigue effects, 236, 250, 356, 363
 - in steel, 321, 328, 431
 - strain (*see* Strain, aging)
- Alloying (*see also* Precipitates)
 - aluminum, 429
 - boron, 295
 - carbon, 332
 - and fatigue, 296, 332, 339
 - hafnium, 295
 - interstitial, 301
 - refractories, 296
 - and rupture strength, 338
 - titanium, 296, 429
 - substitutional, 333
 - Y₂O₃, 429
 - zirconium, 295
- Annealing
 - polygonization, 75
 - recovery, 70, 90, 293, 306, 593, 594
 - recrystallization, 491, 517
 - temperatures, 288

B

- Bauschinger effect
 - modelling, 614, 615
- Biaxial stress state, 678 (*see also* Combined stress state)

C

- Calibration, 211
- Carbides (*see* Composites; Precipitates)
- Cavitation
 - boundary sliding, 46
 - crack initiation, 46, 381, 594
 - nucleation, 48, 96, 149
- Cavity
 - linkup and growth, 48, 163, 308, 385, 422, 462, 594, 596
 - nucleation, 46, 381, 462, 576, 594
 - shape, 64
 - stability, 48, 465, 594
 - and strain, 594
 - and stress, 386
- Cermets, 519
- Coatings
 - cracking, 58, 411, 413, 651
 - effects, 51, 58, 168, 174, 235, 277, 279, 287, 410, 412, 651, 652
 - formation of, 410
 - fracture strain, 58
 - lifetime, 58, 235, 401, 409, 411, 651
 - morphology, 412, 414, 652
 - strain intensity factor, 176
 - temperature effects, 176, 235
 - testing of, 246
- Codes, 733
 - applicability, 734
 - considerations in coding, 733
 - engineering standards, 736
 - formulation procedures, 737
 - improvement, 739
 - influences on, 737

- interpretation, 738
- public safety, 734–736
- rules for elevated temperature, 735, 771
- standardization, 736, 739
- and technology, 734, 740
 - development, 742
- Combined stress states, 29, 231, 462
 - 595, 597, 678, 707
 - in ratchetting, 537
- Composites
 - carbide fiber, 519
- Composition (*see* Alloying)
 - effects (*see* Precipitates; Material types)
- Computer use, 211, 258, 588, 596, 714
 - in ductility exhaustion, 629
- Constitutive equations (*see* Equations)
- Continuum theory, 588, 604
- Corrosion (*see also* Oxidation)
 - as failure cause, 231
 - fatigue, 233, 274, 482, 667
 - hot, 287, 410
 - intergranular, 517
 - resistance, 332, 438
 - stress, 482
 - testing, 195
- Crack
 - arrest, 425
 - branching, 422
 - closure, 181, 252
 - coalescence, 502
 - environment, 44, 410
 - fatigue, 139, 175, 201, 345, 416
 - activation energy, 142
 - growth rate, 25, 46, 51, 113, 116, 125, 140, 157, 163, 167–169, 201, 243, 308, 345, 349, 387, 393, 417, 421, 449, 482, 509, 586, 604, 728, 764
 - frequency effects, 117, 350, 351, 353, 586, 763
 - oxygen effects, 53, 117, 763
 - and properties, 395–397
 - and temperature, 27, 174, 177, 509
 - and transition with temperature, 391
 - unstable, 151
- and hysteresis loop, 339
- initiation (nucleation), 5–9, 17, 21, 39, 46, 50, 90, 113, 128, 146, 149, 243, 246, 292, 296, 320, 404, 410, 412, 413, 417, 424, 439, 449, 500, 502, 503, 509, 526, 576, 586, 604, 652, 671, 679, 705, 745, 764, 772
- creep dependency, 43, 498
- laws, 765
- sites, 43, 96, 250, 251, 279, 292, 296, 404, 410, 411, 422, 433, 441, 448, 470, 494, 504, 507, 518, 558, 586, 652
- instability, 151
- intergranular, 49, 127, 128, 250, 251, 362, 424, 650
- length, 168, 509
 - critical, 44, 387, 594
 - initial, 126, 158, 159, 185, 488
 - measurement, 201, 417
- mechanisms, 43, 44, 404, 410, 422
- microcracks, 7, 523, 728
- mode, 26, 169, 176, 422, 434, 444, 501, 586, 630
 - prediction, 50
 - and strain rate, 134
- nucleation (*see* initiation)
- opening displacement, 9, 158
- path, 128, 136, 250, 324, 362, 422, 434
- precracking of specimens, 348
- propagation, 6, 39, 46, 90, 113, 125, 139, 166, 168, 171, 243, 246, 307, 320, 345, 350, 404, 412, 416, 419, 420, 424, 439, 482, 501, 508, 509, 526, 586, 679, 705, 745, 772

- in air, 404
- and alloying, 295 (*see also* Alloying)
- control in testing, 388
- frequency effect, 26, 112, 114, 117, 351, 432
- and precipitates, 170 (*see also* Precipitates)
- rapid, 46, 170, 172
- rate (*see* Crack, growth rate)
- and temperature, 26, 419
- resharpening, 53, 171, 174, 594
- shape, 411, 422
- size, 125, 174, 188
- slip band, 51 (*see also* Dislocation)
- stages
 - I; 38, 44, 292, 442, 449, 586
 - II; 38, 44, 53, 442, 449, 587
- subsurface, 53
- surface, 51, 127, 130, 136, 308, 434, 470, 486
- thermal, 242
- tip, 44, 46, 146, 171, 180, 308, 420, 471, 486, 509, 586
 - blunting, 162, 296, 308, 594
 - heating, 526
 - radius, 158
 - stresses, 508, 579, 766
- transgranular, 127, 128, 404, 448, 650
 - holdtime, 49, 362
- transition, 46, 58, 127, 362
- triple point (wedge), 50, 119, 150, 384, 594
- Creep
 - cavitation, 48
 - component, 50, 614, 663, 748
 - compressive, 48, 49, 476, 499, 659, 665
 - crack initiation, 21, 43, 145, 462
 - cracking, 46, 462, 588
 - damage, 176, 321, 366, 369, 482, 580, 745 (*see also* Damage)
 - deformation (*see* Deformation)
 - failure, 162, 381, 688
 - fatigue interaction, 21, 114, 149, 157, 166, 168, 175, 224, 349, 355, 366, 368, 402, 462, 469, 492, 496, 502, 575, 582, 588, 603, 619, 625, 627, 638, 641, 644, 649, 658, 670, 676, 688, 705, 745, 748, 780
 - fracture, 150, 377
 - hold, 49
 - rate, 150, 314, 463, 466, 468, 470, 586, 593, 691, 696
 - resistance, 287, 295, 476
 - rupture, 49, 287, 295, 470, 580, 650, 746
 - strain, 21, 366, 628, 642, 671, 690, 706, 713, 748
 - and frequency, 153, 642, 663
 - strength, 498, 626
 - subgrains, 71, 75
 - tensile, 48, 49, 476, 499, 659, 665
- Crystal
 - polycrystalline versus columnar, 410
 - structure, 301
- Cyclic
 - cell formation, 76, 301
 - control, 225
 - creep, 149, 158, 650, 671
 - deformation, 305, 306, 479, 671
 - energy, 476, 478, 479
 - growth (*see* Ratchetting)
 - hardening, 90, 132, 302, 324–327, 373, 463, 465, 623, 686, 712
 - plasticity, 169, 171, 345, 603
 - plastic strain, 30
 - rupture, 452, 460
 - softening, 90, 132, 463, 465, 616, 623, 686
 - strain hardening exponent, 11
 - stress, 293, 463, 553
 - thermal, 650 (*see also* Cycling, thermal)

stress-strain curve, 126–128, 224,
326, 475, 476, 679, 712
model, 614, 679
serrated, 306

Cycling

A-ratio, 440
bend, 453, 701
compressive, 48
frequency dependence, 112, 351
in fatigue, 114, 555, 576
push/pull (fully reversed), 48, 83,
125, 301, 321, 356, 367, 440,
478, 483, 493, 513, 524, 555,
627, 638, 649
R-ratio, 158, 348, 432
random (temperature), 104
reverse bend, 233, 321, 483, 513,
524
sonic, 256
stability, 651
strain, 167, 195, 334, 366, 473,
482, 491, 553, 577, 582, 627,
638, 651, 771
stress, 248, 265, 451
thermal, 83, 167, 195, 197, 227,
232, 246, 266, 311, 316, 366,
402, 451, 473, 477, 491, 496,
500, 555, 619, 649, 665, 681
torsional, 48, 513
wave form, 637

D

Damage (*see also* Holdtime)

accumulation, 224, 355, 594, 596,
670
and energy, 477
linear, 18, 114, 366, 579, 627,
633, 650, 670, 674
rate, 154
creep, 224, 304, 308, 350, 355, 366,
368, 372, 373, 475, 480, 498,
579, 642, 644, 705, 708, 767
cumulative, 81, 95, 176, 321, 366,

478, 500, 506, 508, 548, 582,
626, 630, 645, 705, 757
fatigue, 91, 134, 224, 321, 368,
372, 431, 475, 480, 498, 633,
652, 705, 707, 708, 729
holdtime, 320, 506 (*see also*
Holdtime)
fraction, 675
function, 595
Miner's rule, 91, 508
plot, 627
recovery, 595
rules, 19, 368, 478, 548, 577, 582,
603, 626, 628, 650, 707, 746,
751, 757
surface, 302, 304, 305, 308, 504,
524

Decarburizing

and properties, 335, 690

Defect (*see* Cavity; Crack; Flaws; Voids)

Deformation

behavior, 616
creep, 151, 499, 626, 671, 691
and gamma prime, 295, 429
inelastic (*see* Strain)
mechanical twinning, 128, 486,
490
nonhomogeneous, 305, 433, 508
plastic, 46, 251, 287, 295, 499, 523,
671 (*see also* Strain, plastic)
in crack growth, 151

state, 7

time independent, 151, 671
work hardening, 90, 504 (*see also*
Cyclic, hardening)

Dendrite

interdendritic cracking, 404 (*see*
also Crack)
spacing, 404

Design, 17, 226 (*see also* Lifetime)

and codes (*see* Codes)
of experiments, 212, 250, 258, 264

Design parameter plots, 638, 644
(*see also* Creep, fatigue interaction; Holdtime)

Diffusion

of carbon, 333
coatings, 236, 410
in LCF, 80, 748
 mechanism, 91
 self, 592
vacancy, 594, 729
volume, and crack growth, 139,
 145, 147

Dislocation

arrangements, 69, 70, 305, 433,
 449, 587
bowing mechanisms, 292
cell formation, 69, 70, 76, 125,
 302, 305, 434
 inhomogeneity, 305
 size, 306, 434
climb, 38, 51, 77, 463, 592
concentration, 44, 433
cross slip, 38, 51, 77, 125, 301
density, 85, 90, 305, 450, 592, 593,
 615, 630
frequency effects, 38
jogs, 463, 594
locking, 304
loops, 70, 71
mobile, 70
mobility, 91, 305, 463, 587, 592,
 594, 616
multiplication, 305, 616
pinning, 61
strengthening, 306
subgrain, 70
substructure, 69, 80, 85, 302, 304
superlattice, 440
tangles, 70, 433, 471, 729
velocity, 592, 614

Driving force

in crack growth, 144, 147, 420

Ductility, 295, 402

in creep, 151, 582, 586, 597, 651,
 754, 762

and crack growth, 395

cyclic, 662

ductile rupture, 308, 594, 762

exhaustion, 625–634, 657, 747

and fatigue, 16, 409, 632, 754

fraction, 597

and strain range partitioning, 661

Dwell (*see* Holdtime)

E

Energy equation (constitutive theory), 606

Environment, 195, 243, 482, 584

air, 51, 112, 233, 296, 321, 329,
 348, 356, 401, 404, 410, 459,
 584

argon, 296

and coatings, 235, 279, 413

control, 211

and frequency, 24, 112, 114, 119,
 432, 584

gaseous, 44, 51, 235

humidity, 140

iodine, 482

kerosine, 513, 517

nitrogen, 140

oxygen, 21, 51

 and frequency, 117, 432, 777

protective, 762

PbO, PbBr₂, PbSO₄, 235

salt, 268, 270

simulation, 256, 274, 773

sonic, 262

SO₂, 296

steam, 273, 324, 329

vacuum, 21, 51, 296, 324, 329,
 452, 491, 584, 777

V₂O₅-NaSO₄, 296

Equations

basquin, 14

bowie, 169

- Coffin-Manson, 12, 153, 225, 452, 480, 487, 577
 - constitutive, 588, 621
 - damage (*see* Damage, rules)
 - Hall-Petch, 302-305
 - high temperature fatigue, 11, 17, 25 (*see also* Lifetime, prediction)
 - Manson universal slopes, 15
 - Miner's rule (*see* Damage)
 - Neuber's rule, 30, 584, 681
 - Paris equation, 141, 180, 351, 391
 - ratchetting, 570
 - Stowell, 478, 584, 680
 - ten percent rule, 496, 579, 745
 - universalized life, 754
 - universal slopes, 579, 652, 745
 - Erosion, 656
 - Extensometers
 - analog strain, 197, 356
 - design, 208, 474
 - effects, 10, 324, 494
- F**
- Failure (*see also* Creep; Fatigue; Fracture)
 - criteria, 6, 7, 17, 18, 226, 233, 274, 324, 335, 440, 478, 495, 586, 594, 595, 603, 629, 632, 647, 650, 654, 659, 665, 671, 683
 - energy, 478
 - location, 270 (*see also* Crack, initiation, sites)
 - Failure mechanisms, 761
 - crack initiation, 44
 - brittle boundary phases, 119
 - shear, 50
 - creep, 119, 470
 - diffusion control, 91, 93, 144, 147
 - mode, 502, 629, 749
 - and models, 614
 - propagation, 44
 - slip control, 91, 93
 - Fatigue (creep interaction), (*see* Creep)
 - and alloying (*see* Alloying)
 - coatings (*see* Coatings)
 - crack, 25, 38, 113, 125, 139, 150, 180, 187, 348, 416, 441, 518, 579, 582, 587
 - oxidation, 25, 53, 518
 - endurance, 127, 130, 180, 321, 324, 674
 - and grain size, 288, 304
 - high cycle, 9, 274, 524
 - intergranular, 38, 46, 51
 - isothermal, 172
 - life (*see* Lifetime)
 - limit, 185, 301
 - low cycle, 68, 172, 287, 332, 339, 355, 452, 524, 650, 678
 - frequency modified equation, 113, 153, 452, 579 (*see also* Frequency)
 - of oxide coatings, 94, 102
 - and ratchetting, 553
 - resistance, 29, 50, 253, 292, 301, 388
 - striations, 46, 162, 251, 280, 307, 308, 362, 446, 449
 - subgrain size, 75
 - thermal, 37, 49, 108, 167, 170, 172, 199, 238, 242, 287, 296, 401, 402, 410, 413, 417, 419, 553, 582, 586, 665, 767
 - transgranular, 38, 50 (*see* Cracks, stage II)
 - ultrasonic, 280
 - Finite element analysis, 6, 7, 30, 420, 598, 604, 613, 616, 621, 680, 689, 706, 710
 - Flaws (*see also* Cavity; Crack)
 - already existing, 387
 - distribution, 724
 - size, 724
 - critical, 725

shape, 724
 echo ratio, 724
 Fluidized bed, 242, 416
 Forging
 effect on fatigue, 237, 329
 Fracture
 appearance, 162, 170, 251, 307,
 308, 425, 449, 471, 501
 cleavage, 46, 130, 449, 470
 cyclic, 46
 dimples, 162, 308, 381
 ductile, 377, 381, 470, 566, 594
 fatigue, 195, 307, 308, 324, 469,
 470, 639
 grain boundary (*see* Grain,
 boundary)
 interdendritic, 170
 intergranular, 21, 46, 70, 119, 289,
 308, 433, 462, 470, 594, 745,
 749
 oxygen, 51, 56
 mechanics, 6, 9, 166, 345, 350,
 353, 387, 419, 587, 679, 723,
 728, 764
 mechanism, 307, 309, 587, 748
 mode, 21, 24, 25, 112, 172, 289,
 308, 360, 384, 433, 470, 471,
 749
 shear, 50
 strain, 91, 450, 674
 stress, 723
 surface, 170, 279, 308, 361, 377,
 449, 466 (*see also* appearance)
 and temperature, 301
 transgranular, 44, 119, 170, 289,
 308, 381, 749
 oxygen, 51
 toughness, 182, 394
 Frequency, 12 (*see also* Strain rate;
 Holdtime)
 and crack growth, 280, 345, 350,
 351, 353 (*see also* Crack)
 and creep component, 50, 152,
 154, 582

effect, 15, 38, 58, 112, 152, 199,
 273, 280, 321, 432, 451, 454,
 457, 459, 460, 480, 576, 582,
 603, 637, 642, 643, 663, 674,
 696, 746, 753, 759, 776
 and environment, 112, 280, 586,
 757, 761
 and oxidation, 53, 108, 117, 273,
 280, 459
 ranges, 113
 ultrasonic, 273
 and temperature, 63, 108, 351,
 603, 746

G

Grain (*see also* Single crystals)
 boundary, 44
 cracking, 25, 120, 130, 134, 381,
 384, 422
 damage, 154, 304, 308, 630, 651,
 748
 embrittlement, 301
 fracture, 119, 134, 295, 434
 hardening, 306
 ledges, 305
 migration, 46, 48, 85, 470
 orientation, 404
 oxidation at, 53, 296, 586
 precipitates, 70, 295, 361 (*see
 also* Precipitates)
 serration, 85, 94
 shape, 296
 shear, 48
 sliding, 46, 96, 119, 150, 296,
 379, 435, 594, 596, 748
 strength, 128, 295
 transverse, 289
 orientation, 401, 449
 refinement, 287, 288, 292
 size, 50, 130, 287, 301, 306, 307,
 402, 404, 412, 465, 470, 488,
 652
 and LCF, 288, 301
 structure (duplex), 288

subgrain
 boundaries, 85
 misorientation, 70
 size, 306
 substructure, 70, 80, 306
 twist boundaries, 70
 Gripping, 198
 design, 205

H

Hardening (*see* Cyclic; Strain)

Healing, 726 (*see also* Stress, mean)

Heat

affected zone (HAZ), 588, 690
 in ferritic welds, 151
 methods in testing, 202
 treatment effects, 250, 333, 346,
 355–357, 485, 488, 506, 515
 (*see also* Annealing)

History effects, 591, 613

modeling, 620

Holdtime (*see also* Frequency)

in cyclic creep, 154, 158 (*see also*
 Creep, fatigue)

creep, 154, 627, 632, 696, 746, 760,
 761

component, 19, 50

compressive, 49, 366, 474, 482,
 506, 576, 638, 643, 746

tensile, 49, 125, 134, 366, 367,
 372, 474, 482, 506, 638, 641,
 746

endurance, 136, 576 (*see also*
 Lifetime)

in fatigue, 17, 19, 27, 321, 326,
 356, 357, 362, 366, 372, 402,
 408, 452, 474, 475, 478, 482,
 486, 488, 496, 516, 586, 597,
 637, 639, 670, 702, 705, 706,
 746, 760, 761

and particle size, 293

in ratchetting study, 710

saturation, 360, 372, 638, 642, 760

slip dispersal, 38 (*see also* Slip)

and strain rate, 643

threshold, 368

transition, 583, 603

Hysteresis loop, 27, 197, 225, 453,
 476, 477, 483, 673

in energy approach, 479

in partitioning approach, 658–
 660, 753

ratchetting, 548

stability, 477, 650, 748, 753

I

Interaction (*see* Creep, fatigue)

damage rule, 751

Interspersion (*see* Creep, fatigue in-
 teraction; Damage, cumula-
 tive)

J

Joint efficiency, 694

L

Lifetime

coatings, 410–412

of cermet, 519

crack stages, 25, 38, 404, 410

in creep fatigue, 149, 158–162,
 367, 470, 480, 498, 638, 643,
 663, 665, 671, 746, 749, 753,
 757

design, 5, 15, 49, 633, 670, 678,
 694, 697, 704, 707, 771

endurance, 180, 435, 440, 448,
 450, 501, 503, 506

fatigue, 44, 61, 83, 112, 126, 166,
 268, 273, 301, 304, 307, 368,
 429, 448, 451, 456, 475, 482,
 496, 501, 530, 558, 561, 586,
 597, 663, 670, 694, 699, 703,
 706, 728

frequency modified, 12, 16, 25,
 339, 357, 404, 409, 410, 452,
 745

fatigue transition, 15, 454
 frequency effect, 459
 initial crack length, 158
 notch effect, 498, 502, 678
 partitioned strain range, 660, 751–753
 porosity, 43, 477 (*see also* Cavity)
 prediction, 69, 91, 113, 126–128, 576, 582, 597, 603, 617, 622, 631, 639, 650, 660, 663, 665, 667, 678, 683, 694, 745, 764, 770
 in crack growth, 151–153, 186, 295, 394
 energy method, 478, 479
 with holdtime, 134, 368, 602
 service, 57, 679
 surface effects (*see* Surface, preparation)
 Load ratio (*see* Cycling, R-ratio)

M

Machining

effects, 526–530
 parameters, 524

Material types

aluminum, 301
 base alloys, 46
 1100; 24
 2024; 24
 2618-T6; 512
 5052; 157
 5454; 139
 7075; 145, 163
 Cu; 501
 Mg; 139
 Brass
 alpha, 301
 high Zn, 38
 Cermet, 519
 Cobalt base
 MAR-M 302; 402
 MAR-M 509; 167
 WI-52; 402

FSX-414; 416
 Hastelloy-X, 256
 Haynes Alloy 25; 256, 295
 iron, 301
 magnesium
 alloys, 50, 124
 Nickel A, 24
 nickel-base superalloys, 474
 ATGW2; 517
 B1800; 618
 B1900 W/Hf; 167, 409, 627, 649
 In 100; 295, 649
 In 713; 518
 In 718; 24, 523
 In 738; 295
 In 751; 237
 In 853; 292, 427
 In X-750; 463
 MAR-M200; 26, 38, 167, 291, 409, 649
 Monaloy; 350, 409
 Nickel A; 24
 Nimonic alloys; 296
 Nimonic 90; 517, 649
 Nimonic 100; 517
 713 C; 296
 Alloy 800; 366
 901; 288
 Ni-Cr-Al alloys, 291
 René 41; 256
 René 77; 416
 René 80; 523
 René 95; 523
 stainless steels
 austenitic, 38, 114, 671
 low carbon, 46
 18Cr-12Ni-Cb; 92, 377
 20Cr-25Ni-Cb; 125
 A286; 23, 112, 451
 304; 11, 49, 69, 276, 355, 366, 387, 403, 553, 637
 316; 49, 69, 355, 387, 659, 690
 321; 387

- 347; 24
- 348; 387
- V57; 452
- steel
 - ferritic; 116, 311, 690
 - low alloy (Ni,Cr,Mo,V), 67
 - low carbon, 81, 113
 - C1010; 24
 - C1018; 24
 - $\frac{1}{2}$ Cr, Mo-V; 320
 - $2\frac{1}{4}$ Cr, MoV; 332, 659, 690
 - A212B; 345
 - A302B; 553
 - A517F; 345
 - 9Ni-4Co-0.30C; 345
 - JIS-SCM-3; 553
 - 21-4N; 238
 - 21-2N; 238
- tantalum, 24
 - ASTAR 811C; 491
 - T-111; 491
- titanium, 264
- TDNi; 292
- Udimet 500; 21
- Udimet 700; 26, 46, 288, 409, 618
- Udimet 710; 439
- Waspaloy, 292
- Zircaloy-2; 482
- Zircaloy-4; 483
- Microstructure
 - changes (during fatigue), 83, 361, 479, 630
 - and coatings, 410
 - control, 287, 356
 - and crack growth, 346, 422, 432, 501, 509
 - and fatigue, 287, 321, 328, 432, 479, 486
 - refinement, 401, 404
 - in low-cycle fatigue, 80, 356, 362
 - stability, 491
 - twinning, 486, 728
- Modulus, 169
 - effect on life, 404
 - secant, 584, 680
- N
- Neutron irradiation, 488, 623
- Nondestructive tests, 722
 - acoustic
 - emission, 725, 728, 729
 - holography, 725, 728
 - applicability, 705, 725
 - defect standards, 724
 - exoelectron emission, 729
 - optical, 731
 - positron half-life, 731
 - pulse echo, 726
 - reliability, 722
 - in service, 726
 - signature-baseline generation, 728
 - slip motion, 729
 - stress gradients, 722, 731
 - ultrasonic, 724
 - in fatigue, 731
 - synthetic apertures, 725, 727
- Notch, 5, 265, 494, 502, 514, 584, 602, 679
 - effect at high temperature, 29, 237, 245, 496, 498, 502, 514, 681, 703, 705
- root, 6, 508
 - strains, 7, 507
- surface, 504
- O
- Oxidation
 - chemistry, 401
 - and crack measurement, 324
 - crack tip, 56, 134, 579, 604
 - fatigue crack initiation, 53, 234, 251, 287, 296, 410, 448, 579, 586, 604
 - film, 23, 51
 - frequency effect, 57, 132, 459, 586

growth rate, 109, 132, 296, 604
 intergranular attack, 404, 437, 470
 layers, 53, 109
 preoxidation, 56
 rate of formation, 53, 109, 110
 resistance, 296, 409, 428, 470, 518,
 652
 surface, 248, 762
 and temperature fluctuations, 102,
 108, 234, 251, 401, 408, 626

P

Plastic

blunting, of crack tip, (*see* Crack,
 tip)
 deformation (*see* Deformation,
 plastic)
 instability, 27, 197, 651
 strain, (*see* Strain, plastic)
 superplastic, 288
 zone, 6, 7, 586
 and life prediction, 134, 586
 measurement, 202
 size, 8, 125, 146, 169, 180, 185,
 397, 426, 588

Porosity (*see also* Cavitation)

fatigue life, 43, 477

Precipitates (*see also* Alloying)

brittle, 51
 carbides, 167, 295, 296, 401, 402,
 410, 433, 448, 491
 CbC, 49
 coherent, 38
 and dislocations, 305, 433, 440,
 442
 dissolution, 292
 distribution, 291, 293, 360, 404,
 432, 439, 463
 fibers, 519
 formation, 378
 free zone, 50
 optimum, 50
 heat treatment, 291

gamma prime, 44, 167, 291, 409,
 429, 439, 470, 630
 growth, 96, 360, 384
 incoherent, 38, 49
 and life, 25, 361, 404, 410 (*see also*
 Lifetime)
 and matrix, 594
 $M_{23}C_6$; 48, 50, 70, 76, 360, 384,
 422
 MC, 43, 167
 oxidation rates, 56, 408
 precipitation, 360–362, 523
 hardening (*see* Strengthening)
 second phases, 48, 504
 shape, 43, 404, 439
 shear of, 292, 440, 630
 size, 43, 293, 404, 410
 stability, 355
 thoria, 49
 volume fraction, 293, 432
 Pseudo stress, 360, 529

R

R-ratio (*see* Cycling)

Radiation damage (*see* Neutron irradiation)

Ratchetting, 17, 27, 197, 624, 747

area effect, 547
 creep, 538, 567
 design, 721
 growth, 541, 709, 715, 720, 761
 isothermal, 536
 combined stress state, 537
 material property changes, 544
 mechanical, 201
 rate, 27
 rules, 715–721
 shakedown, 541, 543, 564, 615
 stability, 566
 strain, 29, 548, 555, 560, 565, 567,
 713
 accumulation, 536, 540, 557,
 566, 597, 715, 762

- hardening, 545, 566, 568, 714
- increment, 567
- stress relaxation growth, 538, 542, 547
- stress-state, 546
- temperature effects, 541, 710
- thermal, 201, 539, 540, 564, 568, 710, 711
- work hardening effect, 568
- Recording, 211
- S**
- Signature-baseline generation (*see* Nondestructive tests)
- Single crystals
 - in fatigue, 410
 - oxidation, 53
- Slip
 - bands, 280, 301, 379, 439, 449, 587, 630
 - spacing, 440
 - character, 38, 69, 291
 - concentration, 292, 449
 - dispersal, 38, 61, 450
 - mechanisms, 80, 91, 94
 - detection, 728, 729
 - offsets, 291
 - planar, 38, 44, 124, 291, 301, 440, 616, 620, 669, 748
 - homogeneity, 38, 46, 51, 449, 616
 - planes, 46, 425, 586
 - decohesion, 448, 450
 - surface, 51, 729
 - traces, 304, 379
 - wavy, 38, 44, 301, 669
 - $> 0.4 T_m$, 38
- Solidification, 250
 - directional, 404, 424, 519
- Sonic response, 256–262
- Specimen
 - applicability, 348, 693
 - bend test, 453
 - compliance changes, 526
 - design, 203
 - for fluidized bed, 245
 - hourglass, 196
 - plastic strip, 348
 - zero gage length, 196
- Stacking fault energy, 69
 - high, 38, 306
 - low, 38, 124
- Strain
 - accumulation (*see* Ratchetting)
 - aging, 12, 61, 120, 187, 530, 571, 593, 666
 - dynamic, 301, 304, 308, 458, 493
 - embrittlement, 350
 - amplitude, 9, 69, 301, 302, 480, 496, 560, 576, 629
 - in bending, 324
 - component, 15, 749
 - concentration, 584, 602, 679, 683, 690
 - and crack nucleation, 149
 - creep (*see* Creep, strain)
 - effective, 678, 679
 - elastic, 773
 - energy, 146, 728
 - gradient, 18
 - hardening, 73, 76, 154, 459, 542, 545, 614, 710, 712
 - and crack growth, 395, 509
 - exponent, 73, 487, 560
 - inelastic, 659, 747
 - intensity factor, 169, 172, 584
 - large, 38, 50, 320, 408
 - mean, 171, 474, 619, 673
 - measurement, 208
 - plane, 185, 701, 712
 - plastic, 112, 308, 404, 473, 482, 483, 536, 659, 663, 671
 - concentration, 304, 305, 308, 584
 - model, 614
 - prestrain, 154
 - range, 57, 70, 90, 91, 132, 168, 326, 368, 372, 402, 404, 417, 454,

- 478, 496, 579, 602, 619, 632,
641–643, 679, 707, 749, 757
- damage summation, 751
- partitioning, 603, 658, 747
- plastic, 12, 454
- ratchet, 555 (*see also* Ratchetting)
- rate, 12, 38, 70, 120, 124, 134, 166,
197, 199, 304, 306, 316, 356,
366, 577, 614, 637, 658–667
(*see also* Frequency)
- at crack tip, 44
- intensity factor, 46
- saturation, 638, 642
- sensitivity, 76, 225, 620
- ratio, 29
- reversal, 17, 658–659, 747
- small, 132
- surface, 320
 - detection, 731
- tensile, 366
- tensor, 621
- yield, 686
- Strength
 - and crack growth, 145, 345
 - creep, 287, 296, 438, 498, 705, 746
 - cyclic parameters, 126, 301
 - and fatigue, 126, 130, 295, 408–
410, 435, 436, 439, 530, 561
 - grain boundary, 128
 - precipitation, 76
 - rupture, 452, 746
 - subgrain size, 74
 - yield, 345, 394, 402
 - compressive, 540
 - and crack growth, 396
 - and temperature, 541
 - tensile, 540
- Strengthening
 - dispersion, 293, 427
 - precipitation, 427, 491, 593
 - solid solution, 76, 167, 427, 491
 - by thermal cycling, 318, 362
- Stress
 - amplitude, 7, 180, 266, 465, 502
 - compressive, 64, 324, 507, 746
 - mean, 449
 - concentration, 44, 246, 253, 584,
671, 679, 680, 703
 - factor, 7, 265, 308
 - constant, 50, 558
 - constraint, 163
 - and creep, 158, 507, 650
 - critical resolved shear, 44
 - dwelt (*see* Holdtime)
 - in fatigue, 46, 128, 130, 666
 - field (distribution), 180, 250, 419,
501, 690, 691, 705, 765
 - friction, 306
 - general yield, 180, 188, 348
 - intensity, 141, 145, 536, 764
 - factor, 145, 164, 180, 183, 391,
419, 420, 509, 584, 587
 - minimum, 188
 - range, 392, 420
 - threshold, 180, 187, 188, 392
 - mean, 17, 29, 159, 167, 180, 188,
266, 269, 439, 440, 449, 506
 - and crack stages, 449
 - creep component, 50, 506
 - healing, 49, 64, 506, 576, 762
 - peak, 324, 327, 530, 753
 - plane, 174, 185
 - and precipitation, 377 (*see* Strain,
aging)
 - raiser, 158
 - effects, 163
 - range, 90, 515, 519, 679, 690
 - frequency modified, 12
 - ratio, 180
 - and crack growth, 186–188
 - relaxation, 17, 29, 134, 154, 327,
366, 369, 505, 517, 583, 601,
614, 642, 695, 747, 760
 - cyclic, 373, 538 (*see* Ratchet-
ting)
 - residual, 29, 183, 505, 507, 508,
523, 529, 565, 601, 691, 731

- response (steady-state), 302, 305, 306, 308
 - rupture, 332, 335, 368, 373, 431, 694
 - saturation, 70, 302
 - grain size, 302
 - subgrain size, 71
 - stress-strain curve (*see* Cyclic)
 - tensile, 324, 507, 515
 - thermal, 242, 256, 404, 408, 541, 598
 - vibratory, 464
 - yield, 304, 345, 394
 - Striations (*see* Fatigue, striations)
 - Sulfidation, 287 (footnote), 296, 410, 427
 - Surface
 - condition and NDT, 731
 - energy (fracture), 50, 150
 - failure, 404
 - preparation (integrity), 7, 236, 277, 508, 516–517, 518, 522, 530, 700
 - roughness, 531
 - stability, 404, 410
 - yield surface, 713
- T**
- Temperature
 - brittle-ductile transition, 413
 - crack growth, 141, 350–353, 391, 395, 498, 510
 - threshold, 391
 - cracking mode, 50, 127
 - creep component, 50, 320, 508
 - and dislocation cell size, 302
 - equivalent, 93–96, 480
 - fatigue effects, 9, 12, 16, 21, 61, 68, 91, 127, 130, 141, 166, 357, 417, 451, 475, 480, 498, 579, 603, 659, 660, 746
 - fluctuations, 312, 478, 498, 501, 503, 510, 712, 746, 769
 - amplitude, 103, 108, 166, 417
 - and oxides, 102
 - and fracture, 21, 479, 498, 510 (*see* Fracture, mode)
 - frequency effects, 63 (*see* Frequency)
 - and grain boundary, 292, 295, 462 (*see also* Grain, boundary)
 - high temperature alloys, 285, 320, 410
 - life prediction, 94, 127, 478, 498, 579, 652, 659, 662–663, 666, 684, 746, 749 (*see also* Life-time)
 - oxidation effects, 51, 53
 - ranges, 102, 225, 690
 - recovery, 70, 75, 90 (*see also* Annealing)
 - strain rate effects (*see also* Strain, rate), 124, 305, 314, 616, 659
 - and testing, 196
 - Test methods, 10, 11, 17, 194, 198, 225, 228, 460, 695, 749
 - data comparisons, 603
 - simulation, 232, 459, 601, 633, 689, 707, 769
 - Thermal
 - cycling (*see* Cycling, thermal)
 - fatigue (*see* Fatigue, thermal)
 - ratchetting (*see* Ratchetting, thermal)
 - strain (in creep), 601
 - stress, 5, 151, 500 (*see also* Stress, thermal)
 - Thermal protection system, 255
 - Time (*see* Creep; Cycling, ratio; Frequency; Holdtime)
 - dependent mechanisms, 592 (*see* Creep)
 - independent mechanisms (*see* Fatigue)
 - fraction rule, 584, 674 (*see also* Damage, rules)

in strain range partitioning, 666
 testing cycle, 195
 Twinning (*see* Deformation; Micro-
 structure)

U

Ultrasonic measurement (*see also*
 Nondestructive tests)
 crack growth, 139

V

Vacancies
 annihilation, 463
 condensation, 46, 463, 471
 flow, 592 (*see also* Cavitation)
 pinning, 463
 production, 48
 supersaturation, 48

Vacuum (*see also* Environment)
 life effects, 51, 757 (*see also* Life-
 time)
 and frequency, 112, 114, 757 (*see*
also Frequency)

Vapor deposition
 of coatings, 413

Variables in testing, 214, 224

Voids (*see* Cavitation; Cavity)
 formation, 576
 growth, 595

W

Weld and design, 688, 699
 fatigue in, 587

X

X-ray
 analysis for subgrains, 85–87
 integral breadth ratio, 87